

# GD315 Multi Coin Acceptor User Manual

## Product features:

- 1) Automatic identify coins' diameter, thickness, and material.
- 2) Can set three different currency groups at the same time, each group can set 15 coins.
- 3) Can adjust the accuracy of the coin register at any time, and is suitable for the needs of different places.
- 4) With software monitoring system, fishing stop, and alarm device, safe and reliable.
- 5) Can connecte with coin meter
- 6) Provide digital output and modify output function as required..

## Product setting:

- 1) first make the sensitivity switch to the "normal" position ("exact"), then turn the setting switch to "set", and LED show "00" (show "P2")
- 2) press the currency switch in turn to make the LED show the value you need.
- 3) put coins you want to set in order, you can set up 15 coins at most, no more than 15, and then you can add storage at any time.
- 4) after setting the first coin, if you need to set another coin, and then repeat the second and third steps, if you want to exit, make the setting switch to start, then can use.
- 5) when you want to cancel all coins that have been set, when you execute the first step, the LED shows "00", hold the currency adjustment switch 2 seconds then hear "BI" sound and LED show "C" then is ok
- 6) if you want to cancel the use of a certain set of value coins, the implementation of the first and second steps, press and hold the currency adjustment switch 2 seconds after hear "BI" sound, and "LED" shows "C" then is ok.

Specifications and instructions for use:

Applicable coin diameter: 18mm-29mm

Applicable coin thickness: 1.2mm-3.0mm

Operating voltage: DC12V + 20%

Temperature: - 50 DEG C.

- 1) with the specifications of the machine, switch NO (open) NC closed) switch; in addition to Big Mario machine, normally set with NO(open).
- 2) Coordinate to the speed of the machine ,can set coin signal speed with three stage switch (TIME SWITCH): fast, middle and slow.25ms for fast(use with the machine need rapid and large coin), 45ms for medium speed coin signal (most of machine suitable for this), 65ms coin signal slow (for the machine not need drop coin frequently)
- 3) coin setting switch, when the coin exchanger is newly used, you must switch the key and set the coins you want to use.
- 4) coin value adjustment button switch, when set value of coins, set value "00-99" for setting output signal frequency , "P2-99" for quantity of coins need to drop, then just have a signal.
- 5) coin detection sensitivity switch, can choose to set sensitive range of accept false coins and the real coin's
- 6) before use or before setting, please electrify for about 10 minutes, you can get the best results..

7)Wiring:

